

Sound Maker (Buzzer)

Purpose Of This Page

This page explains how to play musical notes with the CodyJoy Pro Sound Maker using Python.

The CodyJoy Pro includes several built-in features, including:

- RGB LED Matrix.
- Joystick.
- Sound Maker.

This page focuses only on the Sound Maker.

By the end of this page, students will be able to:

- Play a musical note.
- Choose how long a note should play.
- Use sharp notes such as `F#2`.
- Use flat notes such as `Gb2`.
- Play a note and continue immediately.
- Play a note and wait until it is done.

CodyJoy Pro with Sound Maker

Figure 1 - CodyJoy Pro device. The board includes an RGB LED Matrix, joystick, and Sound Maker.

Start Code

Every CodyNick Python script should import the CodyNick library and connect to the CodyNick device.

```
import CodyNick

cn = CodyNick.CN()
```

The variable `cn` represents the connected CodyNick device.

Play A Note

Use `CJP_Sound_Maker.play()` to play a note.

Function format:

```
CodyNick.CJP_Sound_Maker.play(cn, note, duration_ms)
```

Example:

```
import CodyNick

cn = CodyNick.CN()

CodyNick.CJP_Sound_Maker.play(cn, "F#2", 300)
```

This plays note `F#2` for `300` milliseconds.

The program continues immediately after starting the sound.

Play Until Done

Use `CJP_Sound_Maker.play_until_done()` when Python should wait until the note is finished.

Function format:

```
CodyNick.CJP_Sound_Maker.play_until_done(cn, note, duration_ms)
```

Example:

```
import CodyNick

cn = CodyNick.CN()

CodyNick.CJP_Sound_Maker.play_until_done(cn, "C4", 500)
print("The note is finished")
```

This plays note `C4` for `500` milliseconds. The message is printed after the note is done.

Duration

The duration is written in milliseconds.

Common examples:

Duration	Meaning
<code>100</code>	0.1 second
<code>250</code>	0.25 second
<code>500</code>	0.5 second

Duration	Meaning
1000	1 second

Example:

```
CodyNick.CJP_Sound_Maker.play(cn, "A4", 1000)
```

This plays note `A4` for one second.

Sharp And Flat Notes

Sharp notes use `#`.

Example:

```
CodyNick.CJP_Sound_Maker.play(cn, "F#2", 300)
```

Flat notes use `b`.

Example:

```
CodyNick.CJP_Sound_Maker.play(cn, "Gb2", 300)
```

`F#2` and `Gb2` are the same pitch.

Example: Play A Short Melody

This example plays a short melody using `play_until_done()`.

```
import CodyNick

cn = CodyNick.CN()

CodyNick.CJP_Sound_Maker.play_until_done(cn, "C4", 250)
CodyNick.CJP_Sound_Maker.play_until_done(cn, "D4", 250)
CodyNick.CJP_Sound_Maker.play_until_done(cn, "E4", 250)
CodyNick.CJP_Sound_Maker.play_until_done(cn, "G4", 500)
```

Because `play_until_done()` waits, the notes play one after another.

Example: Melody With A Loop

This example stores notes in a list and plays them in a loop.

```
import CodyNick

cn = CodyNick.CN()

notes = ["C4", "D4", "E4", "F4", "G4", "A4", "B4", "C5"]

for note in notes:
    CodyNick.CJP_Sound_Maker.play_until_done(cn, note, 250)
```

This plays a simple scale from `C4` to `C5`.

Example: Continue Immediately

This example starts a note and immediately continues to the next line.

```
import CodyNick

cn = CodyNick.CN()

CodyNick.CJP_Sound_Maker.play(cn, "C5", 500)
print("This prints while the sound may still be playing")
```

Use `play()` when the program should continue immediately.

Use `play_until_done()` when the program should wait.

Function Summary

Function	Purpose	Example
<code>CJP_Sound_Maker.play(cn, note, duration_ms)</code>	Play and continue immediately	<code>play(cn, "F#2", 300)</code>
<code>CJP_Sound_Maker.play_until_done(cn, note, duration_ms)</code>	Play and wait until done	<code>play_until_done(cn, "C4", 500)</code>

Supported Notes

The Sound Maker supports notes from `B0` to `D#8`.

The table below shows the supported sharp-note notation and approximate frequencies.

Note	Hz	Note	Hz	Note	Hz	Note	Hz
B0	31	C1	33	C#1	35	D1	37
D#1	39	E1	41	F1	44	F#1	46
G1	49	G#1	52	A1	55	A#1	58

Note	Hz	Note	Hz	Note	Hz	Note	Hz
B1	62	C2	65	C#2	69	D2	73
D#2	78	E2	82	F2	87	F#2	93
G2	98	G#2	104	A2	110	A#2	117
B2	123	C3	131	C#3	139	D3	147
D#3	156	E3	165	F3	175	F#3	185
G3	196	G#3	208	A3	220	A#3	233
B3	247	C4	262	C#4	277	D4	294
D#4	311	E4	330	F4	349	F#4	370
G4	392	G#4	415	A4	440	A#4	466
B4	494	C5	523	C#5	554	D5	587
D#5	622	E5	659	F5	698	F#5	740
G5	784	G#5	831	A5	880	A#5	932
B5	988	C6	1047	C#6	1109	D6	1175
D#6	1245	E6	1319	F6	1397	F#6	1480
G6	1568	G#6	1661	A6	1760	A#6	1865
B6	1976	C7	2093	C#7	2217	D7	2349
D#7	2489	E7	2637	F7	2794	F#7	2960
G7	3136	G#7	3322	A7	3520	A#7	3729
B7	3951	C8	4186	C#8	4435	D8	4699
D#8	4978						

Practice Tasks

Try these exercises:

1. Play `C4` for `500` milliseconds.
2. Play `A4` for one second.
3. Play `F#2` for `300` milliseconds.
4. Play the same pitch using `Gb2`.
5. Create a list of notes and play them in a loop.
6. Write a short melody using at least five notes.
7. Compare `play()` and `play_until_done()` by printing a message after each function call.

Common Mistakes

Notes must be written as strings:

```
CodyNick.CJP_Sound_Maker.play(cn, "C4", 500)
```

This is not correct:

```
CodyNick.CJP_Sound_Maker.play(cn, C4, 500)
```

The duration is in milliseconds, not seconds:

```
CodyNick.CJP_Sound_Maker.play(cn, "C4", 1000)
```

This plays for one second.

Use `play_until_done()` when the next note should wait:

```
CodyNick.CJP_Sound_Maker.play_until_done(cn, "C4", 250)
```

```
CodyNick.CJP_Sound_Maker.play_until_done(cn, "D4", 250)
```

If `play()` is used for many notes in a row, later notes may start before earlier notes are finished.

Page summary:

The Sound Maker plays musical notes by name. Use `play()` to start a note and continue immediately, or use `play_until_done()` when Python should wait until the note is finished.

Revision #1

Created 2026-05-15 04:53:38 UTC by Admin

Updated 2026-05-15 04:54:25 UTC by Admin